

Mammoth Swivel & Fixed Couplers







Part No's:

T57420 T57421 T57422 T57423 T57425 T57426 T57430 T57431 T57435 T57436 T57440 T57441



Original Instructions

Rated Load with a Safety Factor of 8:1 WLL1 DGUV/BGV C1 for Lifting Load

Rated Load with a Safety Factor of 4:1 WLL2 2006/42/ES for Static Load

Part No.	Tube Diameter	Description	Finish	Accessory	WLL ¹ (Kg) Lifting	WLL ² (Kg) Static
T57420	Ø60-63mm	Mammoth Swivel Coupler	Polished	Two Clamps Joined	250Kg	500Kg
T57421	Ø60-63mm	Mammoth Swivel Coupler	Black	Two Clamps Joined	250Kg	500Kg
T57422	Ø60-63mm	Slimline Mammoth Swivel Coupler	Polished	Two Clamps Joined	150Kg	300Kg
T57423	Ø60-63mm	Slimline Mammoth Swivel Coupler	Black	Two Clamps Joined	150Kg	300Kg
T57425	Ø60-63mm & Ø48-51mm	Mammoth 63- 51 Swivel 90° Coupler	Silver	Two Clamps Joined	250Kg	500Kg
T57426	Ø60-63mm & Ø48-51mm	Mammoth 63- 51 Swivel 90° Coupler	Black	Two Clamps Joined	250Kg	500Kg
T57430	Ø60-63mm	Mammoth 90° Fixed Coupler	Polished	Two Clamps Joined	250Kg	500Kg
T57431	Ø60-63mm	Mammoth 90° Fixed Coupler	Black	Two Clamps Joined	250Kg	500Kg
T57435	Ø60-63mm & Ø48-51mm	Mammoth 63-51 Fixed 90° Coupler	Silver	Two Clamps Joined	250Kg	500Kg
T57436	Ø60-63mm & Ø48-51mm	Mammoth 63-51 Fixed 90° Coupler	Black	Two Clamps Joined	250Kg	500Kg
T57440	Ø60-63mm	Mammoth Parallel Coupler	Polished	Two Clamps Joined	250Kg	500Kg
T57441	Ø60-63mm	Mammoth Parallel Coupler	Black	Two Clamps Joined	250Kg	500Kg

The Mammoth Coupler range consists of various couplers used to lift loads or make structural connections. Couplers are used in the entertainment market. They can be used for permanent support structures in places of entertainment such as museums, event venues, theatres etc.

Lifting loads is inherently dangerous so Mammoth Couplers are strictly for professional use only. Only competent persons are permitted to install and use Mammoth Couplers. A competent person in this respect is an individual with relevant technical education, training and/or experience enabling him or her to perceive risks and to avoid hazards occurring during use of a product.

The load capacity differs depending on the model and the safety factor required. Couplers are suitable to fit steel and aluminium tubes of diameters ranging from 60mm to 63mm depending on the model. Couplers are marked with the working load limit corresponding to the 8:1 safety factor in order to meet the German standard for overhead lifting.

Most Couplers are available in Silver (polished aluminium) or black powder coating. Special attention has been taken to safety. Therefore the TUV test certificates indicate multiple working loads. Depending on the application or local applicable legislation max working load can be chosen.

Couplers can be judged as a lifting accessories under the EU machine Directive 2006/42/EC as well as German DGUV17 for lifting and holding loads above persons. They can also be used as a joining part in constructions. For this application no harmonised standard is available and no CE Declaration of Performance can be provided. All communications will be carefully considered for future printings of this manual and changes to our products. Some models of clamps are composed of different elements each with an individual Working Load. The lowest of the working loads determines the overall strength and thus shall be used as max working Load for the application.

When Mammoth Couplers form part of a lifting machine or lifting system, the lifting machine or system shall be tested and marked with its WLL and appropriate certification issued. The resulting forces in the structure attached shall be verified before applying a load.



Warning


Check local legislation for the application of use and adapt the use where ever necessary.

The intended use of couplers is to be used as a lifting accessory to hang loads or create a connection between structural elements. Loads can be, but not limited to, lighting fixtures, video projectors, sound systems and stage sets. Structural elements can be pipes, trusses, tubular frame works or lifting brackets.


Any use other than that mentioned is considered to be a case of misuse. The user/operator and not the manufacturer shall be liable for any damage or injury resulting from such cases of misuse. The use of couplers for scaffolding purposes under EN74 is explicitly excluded from the intended use.

- The couplers can be operated in -20° Celsius up to +60° Celsius.
- When used permanently outdoors it is advised to use the versions with stainless steel hardware in order to avoid galvanic corrosion.
- For salt water environments, please use our All Weather Clamp range.
- Mammoth Couplers shall only be used on steel or aluminium tubes or bars.
- When Mammoth Couplers are used as part of an outdoor lifting system special factors such as ground condition and profile, wind loading, water accumulation on temporary structures and other criteria shall also be taken into account.
- When couplers are used to secure equipment which is moved or suspended over areas where persons are present an M12 self-locking nut shall replace the standard nut and wingnut.
- The use of couplers is the sole responsibility of the user.
- To use the couplers the user must also observe the safety regulation, the assembly and disassembly instructions to be found in this manual.
- All persons who use and service this device have to be acquainted with this manual and must be informed about its potential hazards.
- It is also imperative to observe the local accident prevention regulations and/or occupational health and safety regulations.
- Care must be taken when used in conjuction with thin wall truss.
- The manufacturer is not liable for indirect consequential damage and financial loss. The manufacturer shall not be liable for any changes made to the device nor for any damage resulting from such changes.


TYPICAL MAMMOTH 90° FIXED AND SWIVEL COUPLER




TYPICAL MAMMOTH PARALLEL COUPLER



TYPICAL SLIMLINE MAMMOTH SWIVEL COUPLER



TYPICAL MAMMOTH CLAMP LABEL



The following modifications are allowed to be executed by third parties:

Painting:

- To paint a coupler, cover all bolts and nut with tape.
- Use blasting to roughen the surface and to degrease the coupler.
- Use a wet-paint or powder coating paint system to colour the part.

Safety Instructions:


For heath and safety reasons people assembling, disassembling, transporting, maintaining and cleaning Couplers should wear adequate Personal Protection Equipment such as, but not limited to: gloves, hard hats and safety shoes. In line with the use of PPE organisational measures may need to be implemented to keep the area beneath installations clear of personnel.

- Couplers shall be solely used for the range of pipe diameters as stated on the Couplers.
- Do not exceed the working load limit engraved on the Couplers.
- Make sure the resulting forces on the supporting structure are approved by a competent person.
- All loads imposed shall be considered. E.g. dynamic forces caused by the lifting machinery.
- Nuts and bolts shall be tightened by means of a tool in such a manner they cannot be released by man power.
- When loads are using electrical power, equip-potential bonding shall be put in place.
- Couplers shall be inspected by a competent person as often as required but with a minimum of once a year.
- Inspect equipment before every use. Damaged Couplers shall be taken out of service.
- Maintenance and repairs can be undertaken only by authorised personnel. If in any doubt contact the manufacturer.
- Do not throw Couplers.



Warning


The working load engraved on the clamp is solely for a straight pull between the supporting pipe and connectionpoint on the clamp.





Warning


The methods of suspension that are shown below creates torsional forces, influencing the stabillity of the supporting structure and lowers the working load of the clamp. This needs to be checked by a competent person.





Warning


Using clamps where the direction of the load is parallel to the tube depends on, but not limited to, contact surface, material, friction resistance and the applied torque to the clamps wingnut/nut. This type of application significantly reduces the stated WLL and should be used with extreme caution.





Warning

Do not use fixings that, when tightened, will contact the tube or barrel on which the clamp is fixed, as highlighted below.



COUPLERS USED AS A LIFTING ACCESSORY:

2006/42/EC - Machinery Directive.

DGUV Rules 115-002 - Regulations for stages and studios (Formerly known as BGVc1)

DGUV Information 215-313 - Safety at productions and events for television, radio, film, theatre, exhibitions: Loads above persons (Formerly known as BGI 810-3)

BS7906-1:2005 - Lifting equipment for performance broadcast and similar applications. Part 1 specifications for the design and manufacture of above stage equipment.


TRANSPORT AND STORAGE

- Due to the relatively high self-weight it is advised to keep storage bins as small as possible in such a manner they can be lifted by one person. Local legislation for maximum load to be lifted by persons shall be adhered to.
- Before couplers are put into storage they shall be checked for defects. Defective couplers shall be clearly marked and put aside is such a way they cannot be re-used.
- Put the lid and eye bolt together and hand tighten. This way bolts will not get lost during transport.
- Ensure the product is stored and kept in a dry, ventilated environment to avoid corrosion.
- Do not store aluminium couplers in steel bins.
- Use appropriate packaging to prevent damage to parts and threads when transporting couplers.

Mammoth Couplers are used for rigging two sections of truss or barrel together. The couplers consist of two Mammoth clamps bolted together. In the case of the swivel coupler the two clamps are free to rotate relative to each other. With the 90° and parallel couplers the clamps are pinned together so that they cannot rotate.

To install, attach each of the clamps that comprise the coupler to their respective barrel or truss following the intructions below:

- 1. Open the lid of the clamp.
- 2. Fold the eye bolt and lid aside.
- 3. Hang the clamp in the desired position. Tighten the bolt before the load is fully supported
- 4. Tighten the wingnut/nut/bolt using tools only. Do not apply a torque greater than 30Nm/22lbft.
- 5. Use a secondary safety if legislation requires.





Warning

Over tightening the nut or bolt might lead to permanent deformation of the tubes to which they are attached.

COMMISSIONING

- The coupler is not intended to serve as a means to secure electrical bonding and any fixtures must be grounded in accordance with accepted electrical practices.
- Do not use couplers in the immediate vicinity of pyrotechnics.
- If used in an outdoor environment, the support structure must be fitted with earth protection against lightning.
- Before applying a load check that all connections are properly made.
- Before lifting check that all connections are still correct.
- Check if all parts are in good order.

DISASSEMBLY INSTRUCTIONS

- Take the weight off the coupler.
- Release the nut and fold the eye bolt aside.
- Open the lid and fold aside.
- Remove the load.
- Check if the coupler is in good order.
- If not, mark them clearly and put aside.

Table 1	Inspection Level		Items to be Inspected						
	Initial	Regular	Periodic	Lid	Body	Eyebolt	Nut	Roll Pin	ID
Missing Parts	Y	Y	Y						Y
Holes	Y	Y	Y	Y	Y				
Abrasion	Y	Y	Y	Y	Y			Y	
Corrosion			Y	Y	Y	Y	Υ	Y	
Deformation	Y	Y	Y	Y	Y	Y	Y	Y	
Excessive Wear		Y	Y		Y	Y	Y	Y	
Cracks	Y	Y	Y	Y	Y	Y	Y	Y	

INITIAL INSPECTIONS - When first acquired, whether they are new or used, clamps should be inspected in accordance with Table 1 and a record of the inspection maintained.

REGULAR INSPECTIONS - Regular visual inspections should be carried out in accordance with Table 1. Regular inspections should be performed by a competent person and should be carried out prior to each incident of use.

PERIODIC INSPECTIONS - Periodic visual inspections should be carried out in accordance with Table 1 and a record of the inspections maintained. Periodic inspections should be performed by a competent person and should be conducted at least once each year or in accordance with an inspection routine established by a qualified person. Couplers which are subject to any accident must be inspected according to the requirements per periodic inspection and in accordance with Table 1.

INSPECTION FREQUENCY

COUPLERS IN REGULAR SERVICE - Couplers in regular service should be subjected to regular and periodic inspections.

PERMANENT INSTALLATIONS, STATIONARY - Periodic inspections should be carried out on all couplers that are permanently installed in a stationary (not moving) configuration. The frequency of inspections should be determined on the basis of the prevalent conditions.

PERMANENT INSTALLATIONS, MOVING - Periodic inspections should be carried out every three months, or in accordance with an inspection routine established by a qualified person, on all couplers that are installed in a permanent configuration where movement of the truss system is an integral part of use.

RECORDS - Records of initial inspections and periodic inspections should be kept by the owner for each coupler and should be signed and dated by the person carrying out the inspections.



Safety Instructions

Although under normal use and environmental circumstances, couplers need little maintenance, for safety reasons, all parts must be checked regularly for damage, cracks and corrosion.

NOTICE

Mammoth Couplers shall be checked in compliance with the local law by a competent person. Checking shall take place as often as required but at a minimum of once a year. If in doubt contact the manufacturer.

- Approved personnel must carry out a visual and functional test before every useage.
- Check all components for damage and corrosion. Damaged and corroded parts shall be exchanged with like for like approved replacement parts.
- Burrs and sharp edges shall be removed using fine sandpaper or a file. DO NOT use any mechanical abrasive machine to remove sharp edges from the couplers.
- Maintenance and repairs must only be carried out by a competent person. If in doubt, contact the manufacturer.
- Only use hot water and soap to remove dirt from Mammoth Couplers DO NOT use abrasive fluids.
- Do not re-zinc plate steel parts.
- Approved personnel must carry out more detailed inspection and testing of the product on a regular basis depending on the usage of the product.
- Written records should be kept from the date the product was put into operation.




Warning

- The installer/operator must read and understand the User Manual before using the equipment.
- Operators shall be adequately instructed and fully understand the safe use of the equipment before use.
- Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer cannot accept any responsibility in this respect.
- DO NOT modify the equipment as this could lead to a critical failure.
- DO NOT use this equipment for a purpose that it is not intended. This could lead to a failure of the equipment and a risk of falling objects.

The following faults could be an indication of overload or misuse. Remove those couplers from service.

- Deformation of the lid (see diagram).
- Nuts which cannot be turned by hand.
- Eyebolts which do not swivel properly.
- Lids which do not swivel properly.
- Clamp does not fit around the pipe.



Typical Deformation Examples

REPAIRS AND REPLACEMENT OF PARTS

If the Mammoth Coupler is damaged, contact the manufacturer.

DISPOSAL

Products that are no longer needed can be scrapped. Preferably remove all steel parts, store part separately before offering them to a scrapping company. The following alloys are used:

- Aluminium ENAW 6082
- Steel 8.8
- Stainless 304

WARRANTY

- For a period of 12 months we undertake to repair, free of charge any damage attributable to faulty materials or workmanship, provided that the appliance is forwarded, freight paid, to our works or one of the Doughty appointed service agents.
- The guarantee-period begins on the day of the delivery, proven by a purchase receipt like an invoice or delivery note or their copies.
- The guarantee only is applicable for new equipment.
- The guarantee does not cover damage due to transport damage, negligent handling, overload or parts subject to normal wear and tear. Nor damages that originate from a case of misuse because of nonobservance the instructions in this manual.
- The fitting of non-original replacement parts or modifications of design by third parties invalidates the guarantee.
- Guarantee repairs do not renew nor extend the guarantee-period.
- In case of a claim under the guarantee or spare part requirements please contact your Doughty service agent.
- The manufacturer is not liable for indirect consequential damage or financial loss.
- The manufacturer is not liable for any changes made to the coupler or for any damage resulting from such changes.



Product Data Sheet


Mammoth Swivel Coupler







A Mammoth swivel coupler combination which provides a firm fixing between two bars				
Part NosT57420 - Polished T57421 - Powder Painted Satin Black				
Tube Diameter Ø60 - 63mm (2.36" - 2.48")				
Main Body - AW6082 T6 AluminiumMaterialsRoll Pins - Stainless SteelEyebolt - Grade 8.8				
Max Tightening Torque	30Nm			
Fixings	N/A			
WLL	500Kg			
Weight	0.90Kg (1.98 lbs)			
Factor of Safety	5:1			
Approval TÜV Approved				



Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk




Mammoth Swivel Coupler







A Mammoth slimline swivel coupler combination which provides a firm fixing between two bars			
Part NosT57422 - Polished T57423 - Powder Painted Satin Black			
Tube Diameter Ø60 - 63mm			
Main Body - AW6082 T6 AluminiumMaterialsRoll Pins - Stainless SteelEyebolt - Grade 8.8			
Max Tightening Torque	30Nm		
Fixings	N/A		
WLL	300Kg		
Weight	0.90Kg		
Factor of Safety	5:1		
Approval TÜV Approved			



Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk



Mammoth 63 to 51mm Swivel Coupler




Dimensions in mm

Product Data Sheet



A Mammoth coupler and Lightweight coupler swiveling combination which provides a firm fixing between two bars				
Part Nos	T57425 - Polished T57426 - Powder Painted Satin Black			
Tube Diameter Ø48 - 51mm & Ø60 - 63mm				
Main Body - AW6082 T6 AluminiumMaterialsRoll Pins - Stainless SteelEyebolt - Grade 8.8				
Max Tightening Torque	30Nm			
Fixings	N/A			
WLL	500Kg			
Weight	0.90Kg			
Factor of Safety	5:1			
Approval TÜV Approved				



Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk




Product Data Sheet



A Mammoth 90° fixed coupler combination which provides a firm fixing between two bars				
Part Nos	T57430 - Polished T57431 - Powder Painted Satin Black			
Tube Diameter Ø60 - 63mm (2.36" - 2.48")				
Main Body - AW6082 T6 AluminiumMaterialsRoll Pins - Stainless SteelEyebolt - Grade 8.8				
Max Tightening Torque	30Nm			
Fixings	N/A			
WLL	500Kg			
Weight	0.90Kg (1.98 lbs)			
Factor of Safety	5:1			
Approval TÜV Approved				

Mammoth

90° Fixed Coupler



Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk




Mammoth 50 to 60mm 90° fixed Coupler



Product Data Sheet



A Mammoth coupler and Lightweight coupler 90° combination which provides a firm fixing between two bars				
Part NosT57435 - Polished T57436 - Powder Painted Satin Black				
Ø48 - 51mm (1.89" - 2.01") & Ø60 - 63mm (2.36" - 2.48")				
Main Body - AW6082 T6 AluminiumMaterialsRoll Pins - Stainless SteelEyebolt - Grade 8.8				
Max Tightening Torque	30Nm			
Fixings	N/A			
WLL	500Kg			
Weight	0.90Kg (1.98 lbs)			
Factor of Safety	5:1			
Approval TÜV Approved				



Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk



Product Data Sheet



Mammoth Parallel Coupler



			
A Mammoth Parallel coupler which provides a firm fixing between two bars			
Part NosT57440 - Polished T57441 - Powder Painted Satin Black			
Tube Diameter	Ø60 - 63mm		
Materials	Main Body - AW6082 T6 Aluminium Roll Pins - Stainless Steel Eyebolt - Grade 8.8		
Max Tightening Torque	30Nm		
Fixings	N/A		
WLL	500Kg		
Weight	0.90Kg		
Factor of Safety	5:1		
Approval	TÜV Approved		

Doughty Engineering Ltd - Crow Arch Lane, Ringwood, Hampshire, BH24 1NZ, UK +44 (0) 1425 478961, sales@doughty-engineering.co.uk - www.doughty-engineering.co.uk

www.doughty-engineering.co.uk

Inspection List

ITEM	FAULT	REPAIR	DATE	SIGNATURE

EC Declaration



EC-DECLARATION OF CONFORMITY

According to the Machinery Directive 2006/42/EEC Annex II

Doughty Engineering Ltd

Crow Arch Lane Ringwood Hampshire BH24 1NZ

Herewith declares that:

T57420, T57421, T57422, T57423, T57430, T57431, T57440 & T57441

Mammoth Swivel and Fixed Couplers

Are in compliance with the following harmonized standards/standards/regulations.

Machinery Directive 2006/42/EEC annex II

- Machinery Directive 2006/42/EC;
- BS EN 12100:2010 Safety of Machinery General Principles for Design Risk Assessment and Risk Reduction.
- BS 7906-1:2005 Lifting Equipment for Performance, Broadcast and Similar Applications;
- DGUV 17 Regulations for Stages and Studios
- DGUV Information 215-313

Signed for and behalf of Doughty Engineering Ltd

Name Dan Phillips

Position Company Director being the person responsible appointed by the manufacturer.

Company Registration No. London 972614 Registered Office: Crow Arch Lane, Ringwood, Hants, BH24 1NZ Directors: J.C.G. Chiverton. S.C. Wright. D. Phillips. D.M. Chorley



Doughty Engineering

Crow Arch Lane Ringwood Hampshire BH24 1NZ Telephone: +44 (0) 1425 478961 Email: sales@doughty-engineering.co.uk Website: www.doughty-engineering.co.uk

Note: Whilst every effort has been made to ensure that the information contained within this manual is correct, Doughty Engineering does not accept any liability for errors or omissions. Specifications and technical data are intended for guidance purposes only and may vary.